



FIELD SEAL BRACKET FITMENT CHART

MAKE	MACHINE TYPE	MODEL	FIELD SEAL PART NUMBER	BRACKET USED	IMPORTANT NOTES
JOHN DEERE	TRACTOR	8130-8530	FS_TB2 (TRACTOR)	FS_BR29	IF A ROCK BOX OR NO WEIGHT BRACKET IS PRESENT - USE BRACKET FS_BR26
JOHN DEERE	TRACTOR	8225R-8400R	FS_TB2 (TRACTOR)	FS_BR29	IF A ROCK BOX OR NO WEIGHT BRACKET IS PRESENT - USE BRACKET FS_BR26 FOR FRONT 3PT HITCH - USE FS_BR53
JOHN DEERE	TRACTOR	8295RT-8370RT	FS_TB2 (TRACTOR)	FS_BR29	IF A ROCK BOX OR NO WEIGHT BRACKET IS PRESENT - USE BRACKET FS_BR26
JOHN DEERE	TRACTOR	8R 230-8R 410	FS_TB2 (TRACTOR)	FS_BR29	IF A ROCK BOX OR NO WEIGHT BRACKET IS PRESENT - USE BRACKET FS_BR26 FOR FRONT 3PT HITCH - USE FS_BR53
JOHN DEERE	TRACTOR	8RT 310-8RT 410	FS_TB2 (TRACTOR)	FS_BR29	IF A ROCK BOX OR NO WEIGHT BRACKET IS PRESENT - USE BRACKET FS_BR26
JOHN DEERE	TRACTOR	8RX 340-8RX 410	FS_TB2 (TRACTOR)	FS_BR33	
JOHN DEERE	TRACTOR	9300T-9630T	FS_TB2 (TRACTOR)	FS_BR23	
JOHN DEERE	TRACTOR	9360R-9620R	FS_TB2 (TRACTOR)	FS_BR4	
JOHN DEERE	TRACTOR	9460RT-9570RT	FS_TB2 (TRACTOR)	FS_BR4	
JOHN DEERE	TRACTOR	9470RX-9620RX	FS_TB2 (TRACTOR)	FS_BR4	
JOHN DEERE	TRACTOR	9R 390-9R 640	FS_TB2 (TRACTOR)	FS_BR4	
JOHN DEERE	TRACTOR	9RT 470-9RT 570	FS_TB2 (TRACTOR)	FS_BR4	
JOHN DEERE	TRACTOR	9RX 490-9RX 640	FS_TB2 (TRACTOR)	FS_BR4	
JOHN DEERE	TRACTOR	9RX 710-9RX 830	FS_TB2 (TRACTOR)	FS_BR69	
JOHN DEERE	COMBINE	ALL 50 SERIES STS	FS_TB1 (COMBINE)	FS_BR25	
JOHN DEERE	COMBINE	ALL 60 SERIES STS	FS_TB1 (COMBINE)	FS_BR25	
JOHN DEERE	COMBINE	ALL 70 SERIES STS	FS_TB1 (COMBINE)	FS_BR25	
JOHN DEERE	COMBINE	S650-S690	FS_TB1 (COMBINE)	FS_BR25	
JOHN DEERE	COMBINE	S760-S790	FS_TB1 (COMBINE)	FS_BR25	
JOHN DEERE	COMBINE	X9 1000-X9 1100	FS_TB7 (X9 COMBINE)	INCLUDED	
JOHN DEERE	PLANTER	1770NT/1775NT	FS_TB1 OR FS_TB7	FS_BR38	
JOHN DEERE	PLANTER	DB SERIES	FS_TB1 OR FS_TB7	FS_BR42	
JOHN DEERE	PLANTER	1790/1795	FS_TB1 OR FS_TB7	FS_BR76	SPECIFY PLANTER ROW NUMBERS AND SPACING BEFORE ORDERING
JOHN DEERE	SEED DRILL	N540C AND SIMILAR	FS_TB1 OR FS_TB7	FS_BR54	
JOHN DEERE	SEED DRILL	1990	FS_TB1 OR FS_TB7	FS_BR62	
JOHN DEERE	SEED DRILL	560N AND SIMILAR	FS_TB1 OR FS_TB7	FS_BR63	
JOHN DEERE	WINDROWER	W200-W260	FS_TB6	FS_BR39	FITS R SERIES, M SERIES, AND OLDER W SERIES, ALL MODELS
JOHN DEERE	WINDROWER	170 AND MACDON SIMILAR	FS_TB6	FS_BR66	FITS DEERE AND MACDON CANADA
JOHN DEERE	SPRAYER	612R-616R	FS_TB6	FS_BR44	FOR SPRAYERS WITH OIL COOLER USE - FS_BR47
JOHN DEERE	APPLICATOR	800R FLOATER AND SIMILAR	FS_TB6	FS_BR48	
CASE IH	TRACTOR	MAGNUM 210-400	FS_TB2 (TRACTOR)	FS_BR60	FOR OLDER MAGNUMS AND WHEN THERE IS A ROCK BOX - USE FS_BR36
CASE IH	TRACTOR	4WD/QUAD 2014 & OLDER	FS_TB2 (TRACTOR)	FS_BR35	
CASE IH	TRACTOR	STEIGER 350-620 UP TO 2024	FS_TB2 (TRACTOR)	FS_BR108	FOR FRONT SIDE SUITCASE WEIGHT BRACKETS - USE FS_BR73
CASE IH	TRACTOR	QUADTRAC 350-620 UP TO 2024	FS_TB2 (TRACTOR)	FS_BR108	FOR FRONT SIDE SUITCASE WEIGHT BRACKETS - USE FS_BR73
CASE IH	TRACTOR	STG/QDTRC 425-785 2025 & UP	FS_TB2 (TRACTOR)	FS_BR109	FOR FRONT SIDE SUITCASE WEIGHT BRACKETS - USE FS_BR73
CASE IH	COMBINE	7010-8010	FS_TB1 (COMBINE)	FS_BR27	
CASE IH	COMBINE	7120-9120	FS_TB1 (COMBINE)	FS_BR27	
CASE IH	COMBINE	7230-9230	FS_TB1 (COMBINE)	FS_BR27	
CASE IH	COMBINE	7240-9240	FS_TB1 (COMBINE)	FS_BR27	
CASE IH	COMBINE	7250-9250	FS_TB1 (COMBINE)	FS_BR27	
CASE IH	COMBINE	7260-9260	FS_TB1 (COMBINE)	FS_BR27	
CASE IH	COMBINE	130, 088 SERIES	FS_TB1 (COMBINE)	FS_BR59	SOME OVERLAP OCCURS ON 130-140 SERIES. CONTACT US BEFORE ORDERING
CASE IH	COMBINE	150, 140 SERIES	FS_TB1 (COMBINE)	FS_BR49	SOME OVERLAP OCCURS ON 130-140 SERIES. CONTACT US BEFORE ORDERING
CASE IH	COMBINE	2388, 2366	FS_TB1 (COMBINE)	FS_BR68	
CASE IH	PLANTER	1250	FS_TB1 (COMBINE)	FS_BR70	
CASE IH	PLANTER	2150	FS_TB1 (COMBINE)	FS_BR67	
NEW HOLLAND	TRACTOR	T9 SERIES UP TO 2024	FS_TB2 (TRACTOR)	FS_BR108	
NEW HOLLAND	TRACTOR	T9 SERIES 2025 AND UP	FS_TB2 (TRACTOR)	FS_BR109	
CHALLENGER	TRACTOR	ALL MT700 SERIES	FS_TB2 (TRACTOR)	FS_BR32	
CHALLENGER	TRACTOR	ALL MT800 SERIES	FS_TB2 (TRACTOR)	FS_BR32	
CHALLENGER	TRACTOR	ALL MT900 SERIES	FS_TB2 (TRACTOR)	FS_BR32	
FENDT	TRACTOR	900 VARIO MT SERIES	FS_TB2 (TRACTOR)	FS_BR32	
FENDT	TRACTOR	1100 VARIO MT SERIES	FS_TB2 (TRACTOR)	FS_BR32	
VERSATILE	TRACTOR	400-620	FS_TB2 (TRACTOR)	FS_BR30	
VERSATILE	TRACTOR	500DT-620DT	FS_TB2 (TRACTOR)	FS_BR30	
HAGIE	SPRAYER	ALL MODELS 2021 AND OLDER	FS_TB6	FS_BR74	
HAGIE	SPRAYER	ALL MODELS 2022 AND NEWER	FS_TB6	FS_BR58	
KINZE	PLANTER	5900 24R AND SIMILAR	FS_TB1 OR FS_TB7	FS_BR72	SPECIFY PLANTER ROW NUMBERS AND SPACING BEFORE ORDERING

FOR ALL OTHER FITMENT INQUIRES OR CUSTOM BRACKETS, CALL US AT (507)995-2321 OR EMAIL US AT AGSTORM.SALES@GMAIL.COM